

Installation Instructions

SL130 /
SL131




Figure 1



SL130



SL131

FEATURES

Low Energy
Low voltage (driver included)
Long Life - 50,000 hours
IP 40 - Suitable for dry locations only
High powered 1w LED
110° beam angle
Diameter 30mm
Width 30mm
Depth 20mm

WARNING

This product must be wired as described below. Incorrect wiring WILL result in irreparable damage to the LED and driver. Read these instructions fully and carefully.

GENERAL

Thank you for purchasing a quality SI-LITE product. This product has been designed, developed and tested to our strict codes & standards. This product is designed to be powered by a constant current driver, which is built in to the unit. If wired to a conventional transformer, this fitting WILL be destroyed. This product is **NOT** dimmable.

IMPORTANT INFORMATION

Installation should be carried out in accordance with IEE wiring regulations. Always disconnect the mains supply before installation. Connect the unit's attached driver to the mains supply ensuring that it is protected by a fused connection unit. Make sure all electrical connections are tight. Install the fitting as described below.

ASSEMBLY INSTRUCTIONS

1. Isolate the mains supply before installation.
2. Select your desired location and drill a 26mm cut-out circular hole. Insert the fitting (driver / cable first). Spring clips will hold it in place.
3. Connect unit in parallel (fig 1) to the mains supply (brown = live; blue = neutral)
4. If using an in-line switch, only switch the mains side.
5. Check you have followed these instructions fully - incorrect wiring will result in irreparable damage to the LED's and to the driver. SI-LITE performs strict tests on all of our products, and we will not replace products which have been incorrectly wired.
6. Now you can switch on the supply.
7. If in doubt, contact a qualified electrician.

GUARANTEE

This product is guaranteed for a period of 1 year from the date of purchase. The guarantee is invalid in the case of improper use, improper installation or tampering. Should the product fail during the guarantee period it will be replaced free of charge, subject to correct installation and return of the faulty unit. SI-LITE is not responsible for any costs associated with the replacement of this product.